



RECOMMENDED CARE FOR YOUR PAINT FINISH

WASHING PROCESS:

DO NOT wash vehicle in direct sunlight

- Keep one bucket and sponge for body and one bucket and brush for wheels
- Thoroughly rinse vehicle to remove/soften dirt and debris
- Use a liquid concentrate soap and water (ex. Turtle Wax Zip Wax)
- Using a sponge wash vehicle in sections (top down) and thoroughly rinse vehicle
- Dry vehicle using a California Water Blade and Chamois

The California Water Blade can be obtained at any local auto parts store. It will not scratch and does make drying the vehicle faster and easier. Then using a chamois dry around hard to reach areas such as lights, door handles etc...

WAXING PROCESS:

Once vehicle is Clean and Dry apply a GOOD Carnuba Wax (ex. Mothers) to vehicle, using an applicator allow to dry and remove with a cheese cloth or a 3M Perfect-It (Blue) detailing cloth. Part # 39015

If fine scratches need to be removed prior to waxing:

- Use 3M Machine Polish Part # 06064, and a Foam Polishing Pad (Black Waffle)
- 3M Part # 05738 on an electric buffer using 1500 RPM removing fine scratches.
- This can also be done by hand, using the Machine Polish with a soft cloth. If
- "Swirl" marks are present follow with 3M Ultra-Fine Polish Part # 06068 using an Ultra-Fine Polishing Pad (Blue Waffle) Part # 05733 on an electric buffer using 1500 RPM. This process can also be done by hand using Ultra-Fine Polish with a soft cloth.

Follow-UP with waxing Process

NOTE: Use "**EXTREME CAUTION**" when using an electric buffer!!

Use only 1500-1700 RPM Range and be careful of edges as to much speed and heat you will remove paint from these types of areas.